



1

PLACE BASE PLATE UPSIDE DOWN IN POSITION AND ENSURE DOOR CLEARS BASE PLATE.

2

PLACE BASE PLATE UPSIDE DOWN IN POSITION THEN MARK DRILL HOLES

3

DRILL CENTRAL HOLE WITH A 28MM DRILL BIT OR HOLE SAW DEPENDING ON SURFACE. THEN DRILL FIXING HOLES 3MM DRILL BIT FOR WOOD / 10MM FOR CONCRETE OR CERAMIC

4

SCREW BASE PLATE TO FLOOR & SLOT MX-3 INTO CENTRE HOLE

5

DOOR IS NOW RETAINED IN ITS CLOSED POSITION OR INSERT AT 90° DEGREES FOR VENTED FUNCTION

6

SIDE ELEVATION OF PRODUCT IN ACTIVE SETTINGS